



ATHLETIC FIELD COVERS

Installation and removal instructions

DO NOT USE MACHINERY TO INSTALL OR REMOVE THE TARP

Step 1

Roll the culvert with tarp to the edge on left field, lining up with the 3rd base box.



Step 2

Begin unrolling the tarp towards center field until it is completely unrolled. Roll the culvert clear of the tarp.



Step 3

Grab the top edge of the Tarp by the pull straps and pull SQUARELY towards the first base line until deployed. DO NOT pull the handles at an angle.



REMINDER: DO NOT WALK ON THE TARP WITH CLEATS!

REMOVAL PROCEDURE

DO NOT DRAG THE TARP OFF THE INFIELD. DAMAGE WILL OCCUR

Step 1

Fold back the tarp from the first base line and “float” into the outfield. DO NOT DRAG THE TARP ON THE INFIELD DIRT.



Step 2

Line up crew on the third seam (approx. 18' from edge) closest to the left field wall.



Step 3

Grab the tarp at the third seam and pull to the edge of the tarp.



Step 4

Repeat STEP 2 until the tarp is accordion folded to approximately 18' wide.



Step 5

Center a culvert pipe at one end of the fold tarp and begin rolling.



Step 6

To help remove air trapped in the tarp, have two people walk in front of the tarp while rolling.



Brawler recommends a minimum 30” plastic culvert for rolling the tarp